

LTE ROUTER IGV/936-L with eSOM/3517



First Steps



CONTENT

1	INTRODUCTION 3 1.1 Checklist 3 3 1.2 Conventions 3				
2	SAFETY GUIDELINES4				
3	REQUIRED EQUIPMENT				
4	SIM CARD6				
5	CONNECTIONS 7 5.1 LTE Antenna 7 5.2 Ethernet Link 8 5.3 Serial Ports COM2 and COM3 9 5.4 Power Supply 10				
6	OPERATION116.1Booting the IGW/936-L.116.2Accessing the SSV/WebUI116.3Accessing the SSV/WebUI with DHCP enabled126.4LTE Modem Configuration146.5WAN Configuration156.6Firewall Configuration166.7LAN1 Configuration176.8LAN2 Configuration186.9Access via Telnet196.10Access via FTP20				
7	TECHNICAL DATA				
8	PINOUT SCREW TERMINALS22				
9	LED FUNCTIONS23				
10	TROUBLE SHOOTING IP ADDRESS PROBLEMS				
11	I HELPFUL LITERATURE				
со	ONTACT				
DO	OCUMENT HISTORY25				



1 INTRODUCTION

This documentation gives you an overview about the initial operation and the first steps of use with the LTE Router IGW/936-L.

1.1 Checklist

Compare the content of your IGW/936-L start-up package with the checklist below.

If any item is missing or appears to be damaged, please contact SSV!

- ✓ LTE Router IGW/936-L
- ✓ 1x LTE antenna
- ✓ Adapter cable with power and RS232 connector
- ✓ Plug-in power supply
- ✓ Screwdriver
- ✓ Documentation
- ✓ CD-ROM for eSOM/3517



IMPORTANT!

You will need further equipment to operate the IGW/936-L! Please refer to chapter 3.

1.2 Conventions

Convention	Usage
bold	Important terms
monospace	Filenames, Pathnames, program code, command lines

Table 1: Conventions used in this document



2 SAFETY GUIDELINES



Please read the following safety guidelines carefully! In case of property or personal damage by not paying attention to this manual and/or by incorrect handling, we do not assume liability. In such cases any warranty claim expires.

- The power supply should be in immediate proximity to the device.
 - The power supply must provide a stable output voltage between 12 .. 24 VDC ±10%. The output power should be at least 10 W.
- Please pay attention that the power cord or other cables are not squeezed or damaged in any way when you set up the device.
- Do NOT turn on the power supply while connecting any cables, especially the power cables. This could cause damaged device components! First connect the cables and THEN turn the power supply on.
- The installation of the device should be done only by qualified personnel.
- Discharge yourself electrostatic before you work with the device, e.g. by touching a heater of metal, to avoid damages.
- Stay grounded while working with the device to avoid damage through electrostatic discharge.
- The case of the device should be opened only by qualified personnel.



3 REQUIRED EQUIPMENT

To operate the IGW/936-L the following hardware is required:

- a **valid SIM card** with an appropriate mobile tariff. Please refer to **chapter 4** to see how the SIM card is inserted.
- one Ethernet cross-over cable or two Ethernet patch cables and a switch.

To configure the IGW/936-L a PC with the following features is required:

- Windows 7 or higher
- Web browser (e.g. Firefox, Chrome)
- Telnet/SSH client (e.g. TeraTerm)
- FTP client (e.g. FileZilla)
- 10/100 Mbps Ethernet network controller and TCP/IP configuration
- CD-ROM drive



4 SIM CARD

The internal SIM card of the IGW/936-L can be changed through the **slot on the backside**.

To insert the SIM card just push it by hand as deep as possible into the slot.



Please note:

Pay attention to the correct orientation of the SIM card like shown in fig. 1!

Then use a screw driver to push it gently further into the slot until you here a soft "click".



Figure 1: Inserting the SIM card

To remove the SIM card just push it gently with a screw driver until you hear a soft "click" (see **fig. 2**). The SIM card is ejected a few millimeters and can be pulled out easily by hand.



Figure 2: Removing the SIM card



5 CONNECTIONS

For a quick and easy start with the IGW/936-L there are a few cable connections necessary.

The following chapters describe how these connections have to be made.

5.1 LTE Antenna

Connect the LTE antenna with the IGW/936-L like shown in **fig. 3** and place it where the LTE signal strength is high.



Figure 3: Connecting the LTE antenna



Please note:

The best LTE signal strength is achieved by using two antennas. Please contact SSV if you want to order a second LTE antenna.



5.2 Ethernet Link

The Ethernet link between the PC and LAN1 of the IGW/936-L can be made on two ways:

- Direct with an Ethernet cross-over cable like shown in fig. 4.
- With two standard Ethernet patch cables over a hub or switch like shown in fig. 5.



Figure 4: Ethernet link with cross-over cable



Please note:

For the Ethernet connection in **fig. 4** it is absolutely required to use a **cross-over cable**. Do not use an ordinary patch cable. Ethernet patch and cross-over cables are in most cases visual indistinguishable. But the internal wiring is fully different. Mixing up these types of cables leads to LAN errors. Hence pay attention to the label of the cable or packing.



Figure 5: Ethernet link with hub or switch

The IP address of the LAN1 interface is ex-factory set to 192.168.0.126.



5.3 Serial Ports COM2 and COM3

You can create an RS485 serial link on port COM2 and COM3 of the IGW/936-L.

An RS232 serial link is only possible on port COM3.



Figure 6: Serial links on COM2 and COM3

Terminal	Signal
A1	COM2 RS485 Serial Port RX /TX+
A2	COM2 RS485 Serial Port RX /TX-
B4	Signal Ground

Table 2: Screw terminals COM2

Terminal	Signal
B2	COM3 Serial Port: TXD (RS232), RX/TX- (RS485)
B3	COM3 Serial Port: RXD (RS232), RX/TX+ (RS485)
B4	Signal Ground

Table 3: Screw terminals COM3



Please note:

The RS485 (officially called TIA/EIA-485-A) connection between your IGW/936-L and the field devices needs termination resistors on both ends for proper operation. The IGW/936-L **does not offer internal termination resistors**. Please make sure, that the RS485 cable connection is equipped with external termination resistors.



5.4 Power Supply

The IGW/936-L needs a supply voltage of 12 – 24 VDC to work.

Connect the cables of an appropriate power supply to provide the system with the necessary power like shown in **fig. 7**.



Figure 7: Power supply for the IGW/936-L

Terminal	Signal
A3	Vin + (12 24 VDC)
A4	Vin -

Table 4: Screw terminal power



CAUTION!

Providing the IGW/936-L with a higher voltage than the regular 12 .. 24 VDC could cause damaged device components!

Do **NOT** turn on the power supply while connecting it with the IGW/936-L. This could cause damaged device components! First connect the power supply and **THEN** turn it on.



6 OPERATION

6.1 Booting the IGW/936-L

Just power up the IGW/936-L and the boot process starts immediately. The IGW/936-L boots thereby an embedded Linux out of its Flash memory. This may take up to one minute.

6.2 Accessing the SSV/WebUI

To open the login page of the SSV/WebUI enter the ex-factory IP address and port number of LAN1 of the IGW/936-L manually in a web browser:

http://192.168.0.126:7777

Enter the username admin and the password ssvadmin and click on [Login].

IGW/936 SSV/WebUI	
Login	
Password: Login	

Figure 8: Login page of the SSV Web WebConfig



6.3 Accessing the SSV/WebUI with DHCP enabled

If the automatic IP address configuration of LAN1 via DHCP is enabled, you have to check the assigned IP address, which is necessary to access the IGW/936-L via a Telnet client or a web browser.

Therefore open in Windows **Control Panel > Network and Internet > View network computers and devices**. The IGW/936-L should show up in this list.

Testerlaphope inter most			
O ♥ ♥ Netzwerk ►		Vetzwerk durchsuchen	Q
Organisieren 🔻 Netzwerk- und Freigabecenter	Einen Drucker hinzufügen Ein Drahtlosgerät hinzufüger		•
 ★ Favoriten ■ Desktop Downloads Boogle Drive Zuletzt besucht 	Computer (2) Drucker (1) NPI013BDA (HP LaserJet P3010 Series)		
 ibiliotheken iiiiiiiiiiiiiiiiiiiiiiiiiiiiiiii	 Multifunktionsgeräte (1) UTAX_TA:CD 5240L_DC 6240L:NM9233D9 Multimedia (2) 	1	
Computer Computer Undows7_OS (C:) Lokaler Datenträger (Q:) Computer	Netzwerkinfrastruktur (4) IGW936-0280AD20D38B		
IGW936-0280AD20D388 Kategorie Netzwerkadress	in: Netzwerkinfrastruktur ie: Netzwerk 2		

Figure 9: Selecting the IGW/936-L

Just **right-click** on the IGW/936-L to open the properties dialog, where you can see the current IP address of the IGW/936-L like shown in **fig. 10**.

A double-click on the IGW/936-L opens the SSV/WebUI in a web browser.



Please note:

To access the SSV/WebUI, it is important to add the port number **7777** to the current IP address of the IGW/936-L, e.g.: http://192.168.0.126:7777!



etzwerkgerät	
ICW026.0	190 AD 20D 20D
IGW950-02	200AD 20D 36B
Gerätedetails	
Hersteller:	SSV Software Systems GmbH http://www.ssv-embedded.de/
Modell:	IGW936 http://www.ssv-comm.de/products/igw936.php
Modellnummer:	1.0
Gerätewebseit :	http://192.168.0.183/
Problembehandlung	sinformationen
Seriennummer:	0280AD20D38B
MAC-Adresse:	02:80:ad:20:d3:8b
Eindeutige ID: uuid:emblinux-0280AD20D38B-eth0	
IP-Adresse:	192. 168.0. 183

Figure 10: The properties dialog shows the current IP address

Now you are able to access the IGW/936-L via a Telnet client or a web browser.



6.4 LTE Modem Configuration

To configure the modem settings choose from the menu **Network > Mobile**.

Mobile network setting	js		
Modem configuration			
Enable/Disable interface :	✓ 1	▶	Enable or disable interface ppp0
Status :	CONNECTED		Connection status
Modem type :	Sierra MC7304		Installed Modem
Network info :	Telekom.de (LTE)		Network info
Signal in % :	77%	Check signal	Signal strength
ISP settings			
Provider :	D1 🗸	1 2	Choose your provider
SIM PIN :			Enter PIN for your SIM card
Confirm SIM PIN :	💙		Verify entered PIN
Connection settings			
Connect :	On System start 🔍 🔸	4 Disconnect	
DNS configuration			
Use a DNS server address :			Set DNS server
			OK Apply 5 ancel

Figure 11: Mobile network settings

- 1. In the section Modem configuration enable the checkbox.
- 2. In the section ISP settings choose your provider.
- **3.** Enter the PIN of the SIM card.
- 4. In the section **Connection settings** choose **On System start**.
- 5. Click on [Apply].

In the section DNS configuration you can enter a DNS server if needed.



6.5 WAN Configuration

To use the IGW/936-L as an LTE router the WAN (Wide Area Network) settings need to be configured.

Choose from the menu **Network > WAN**.

Wide area network configuration				
WAN configuration				
WAN interface :	Mobile 🔽 ┥	WAN main interface		
WAN watchdog	<u></u>			
WAN test intervall :	Disabled 🗸	Ping check intervall for main interface		
Internet :		Check 2 o check internet connection		
		OK Apply 3ncel		

Figure 12: WAN settings

- 1. In the section WAN configuration choose Mobile.
- 2. In the section Internet click on [Check] to test the Internet connection.
- 3. Click on [Apply].



6.6 Firewall Configuration

Firewall configuration				
Enable service :			•	Enable or disable firewall
irewall and NAT rules preconfigured sets				
All incomming ports closed, VPN allowed :	۲			Best protection for VPN server
Selective ports allowed :	0			This opens more application ports
Jser uploaded script :	0			Use self created rules
orwading with IP-Masquerading and NAT				
nable forwarding :	<			Full routing from internal to WAN interface
irewall and NAT rules script				
Show current settings :		Active rules	Script rules	Show settings and state
		Firewall is on		

Choose from the menu **Services > Firewall and NAT**.

Figure 13: Firewall and NAT settings

- 1. In the section **Firewall configuration** enable the checkbox.
- 2. In the section Forwarding with IP-Masquerading and NAT enable the checkbox.
- 3. Click on [Apply].



6.7 LAN1 Configuration

The IP address of the LAN1 interface is ex-factory set to **192.168.0.126**.

To configure the LAN1settings choose from the menu **Network > LAN1**.

Local area network configuration					
Network configuration for LAN1 (10/100 MBit)					
Enable/Disable interface :		Enable or disable interface eth0			
IP address configuration :	O manually 💿 automatically 🚽	IP configuration through DHCP or static			
Enable/Disable alias IP address 1 :		Enable or disable alias IP address 1			
Enable/Disable alias IP address 2:		Enable or disable alias IP address 2			
DNS configuration					
Use a DNS server address :		Set DNS server			
Primary DNS server :	192.168.0.4	Enter 1st DNS server address			
Secondary DNS server :		Enter 2nd DNS server address			
		OK Apply 2ncel			

Figure 14: LAN1 settings

To enable the automatic IP address assignment via DHCP follow these steps:

- 1. In the section IP address configuration enable the radio button automatically.
- 2. Click on [Apply].



Please note:

After DHCP was enabled, it is necessary to re-log into the SSV/WebUI with the new assigned IP address of LAN1. Please refer to **chapter 6.3** to find out the current IP address.



6.8 LAN2 Configuration

The LAN2 interface is ex-factory disabled.

To enable LAN2 choose from the menu **Network > LAN2**.

Network configuration for LAN2 (10/	100 MBit)	
Enable/Disable interface :	•	Enable or disable interface eth1
P address configuration :	manually O automatically	IP configuration through DHCP or static
P address :	192.168.10.126	Device IP address
Subnet mask :	255.255.255.0	Subnet mask of the local network
)efault gateway :		Enter default gateway address
ONS configuration		
lse a DNS server address :		Set DNS server
Use a DNS server address :		Set DNS server
		OK Apply <mark>2</mark> anc

Figure 15: LAN2 settings

- 1. In the section **Network configuration for LAN2** enable the checkbox. The IP address is preset to **192.168.10.126**.
- 2. Click on [Apply].



6.9 Access via Telnet

To access the IGW/936-L via Telnet please open a Telnet client program (like **TeraTerm**) on your host PC and enter the current IP address* of the IGW/936-L to activate a Telnet session.

In the upcoming Telnet window you can login with the username **root** and the password **root**.

Now you can enter any Linux commands, which will be executed by the IGW/936-L operating system.

File Edit Setup Control Window Help	
Linux 2.6.32 (192.168.0.209) (pts/0)	
emblinux login: root Password: root@emblinux:~# cat /proc/cpuinfo Processor : ARMv7 Processor rev BogoMIPS : 597.64 Features : swp half thumb fastm CPU implementer : 0x41 CPU architecture: 7 CPU variant : 0x1 CPU part : 0x08 CPU revision : 7	7 (v71) mult vfp edsp neon vfpv3
Hardware : eS0M3517 Revision : 0020 Serial : 000000000000000 drwxr-xr-x 1 root root drwxr-xr-x 1 root root	2048 Nov 12 17:54 . 2048 Nov 12 17:54 . 14 Sep 22 2011 VERSION 2048 Nov 12 17:54 bin 0 Jan 1 2010 dev 2048 Nov 12 17:54 flash 2048 Nov 12 17:54 flash 2048 Nov 12 17:54 lib 12 Nov 12 17:54 lib 12 Nov 12 17:54 lib 12 Nov 12 17:54 wedia 2048 Nov 12 17:54 media 2048 Nov 12 17:54 sbin 2048 Nov 12 17:54 lib 12 Nov 12 17:54 lib 12 Nov 12 17:54 lib 2048 Nov 12 17:54 timp -> /bin/busybox 2048 Nov 12 17:54 timp -> /var/tmp 2048 Nov 12 17:54 timp -> /var/tmp 2048 Nov 12 17:54 www 2048 Nov 12 17:54 www





*Please note:

The ex-factory IP address of the LAN1 interface is **192.168.0.126**. If DHCP is enabled, please refer to **chapter 6.3** to find out the current IP address.



6.10 Access via FTP

The IGW/936-L comes with a pre-installed FTP server, which allows the file transfer via Ethernet between a PC and the IGW/936-L. To access the IGW/936-L via FTP use an FTP client like e.g. **FileZilla**.

🔁 root@192.168.0.126 - FileZilla							
Datei Bearbeiten Ansicht Transfer Server Lesezeichen Hilfe Neue Version verfügbar!							
📾 ∗ 🔳 🔄 🗣 Q 🔯 9→ 33 🗶 R 井 🗄 ∞							
Server: Benutzername: Passwort:		Port:	/erbinden				
Antwort: 250 CWD command successful. Befehl: PWD Antwort: 257 "/" is current directory. Befehl: PORT 192, (58), 247, 52,25 Antwort: 200 PORT command successful. Befehl: LUT Antwort: 150 Opening BIMAP mode data connection for '/bin/ls'. Antwort: 250 Transfer complete. Status: Anzeigen des Verzeichnischafts abgeschlossen							
Lokal: e und Einstellungen\KDW\Eigene Dateien\S-Z\Vortraege\N-03-2009\Software\Sour	e) 🗸	Server: /www					~
M-05-2003 M-05-2003 M-10-2007 M-11-2008 M-05-2007 M-11-2008 M-05-2008 M-05-2005 M-05-2006 M-05-2008 M-05-2008 <t< td=""><td></td><td>Control of the second sec</td><td>Dateigröße</td><td>Detetyp</td><td>Zuletzt geändert /</td><td>Berechtigu</td><td>Besitz</td></t<>		Control of the second sec	Dateigröße	Detetyp	Zuletzt geändert /	Berechtigu	Besitz
Dateiname 🔨 Dateigröße Dateityp Zuletzt geändert		🚞 cgi-bin		Dateiordner	11.02.2009 11:08:00	drwxr-xr-x	root ro
→ 72 Python File 26.02.2009 00:09:19 © post_request.c 1.849 C Source file 05.10.2008 16:38:12 © post_request.dss 1.699 CLASS-Datei 14.02.2009 14:41:14 © post_request.html 613 HTML Document 11.10.2008 14:11:40 © post_request.html 613 HTML Document 14.02.2009 14:41:14 © post_request.html 613 HTML Document 14.02.2009 14:41:14 © post_request.html 666 3ava Language 14.02.2009 01:19:16 © TCPClent.html 666 3ava Language 14.02.2009 01:19:16 © TCPClent.py 407 Python File 26.02:2009 00:19:25 © TCPClent.py 407 Python File 26.02:2009 00:10:25 © TCPClent.py 407 Python File 0.90:2:2009 00:10:26 © TCPClent.py 408 PH		g rindex.htm	3.067	HTML Document	07.07.2009 18:10:00	-TW-FF	root ro
		<					>
11 Dateien. Gesamtgröße: 10.059 Bytes	1 Dateien. Gesantgröße: 10.059 Bytes 1 Datei und 1 Verzeichnis. Gesantgröße: 3.067 Bytes						
					Ref Warteschlan	nge: leer	

Figure 17: FileZilla as FTP client to access the FTP server

Use for the FTP login the current IP address* of the IGW/936-L, the username **root** and the password **root**. With this login you have FTP read/write permission in the file system.

The default setting of the root file system after the boot process is **read-only**. There are only three exceptions, which are shown in **table 5**:

Directory	Remark
/flash	R/W directory, non-volatile memory within Flash
/home/root	R/W directory, RAM disk, volatile memory
/var/volatile	R/W directory, RAM disk, volatile memory

Table 5: R/W directories in the file system

The read-only restriction protects all files of the file system. Under ordinary operating conditions it is not possible to overwrite or delete a file which is necessary for the eSOM/3517 within the IGW/936-L.



To disable the write protection just login with the username **root** and the password **root** and enter the following command:

mount / -o remount,rw

This command "mounts, the file system as **read/write**. All files are now writable and deletable. Please pay attention not to damage important system files! With the command

mount / -o remount,ro

the system is set back to the read-only initial condition after the boot process.



*Please note:

The ex-factory IP address of the LAN1 interface is **192.168.0.126**. If DHCP is enabled, please refer to **chapter 6.3** to find out the current IP address.



7 TECHNICAL DATA

Supply voltage 12 – 24 VDC
Power consumption < 15 W
Weight< 0,5 kg
Mechanical Dimensions (LxWxH) 112 mm x 46 mm x 100 mm
Temperature range0° C – 60° C
Rel. air himudity max. 85%

8 PINOUT SCREW TERMINALS

The table 6 shows the pinout of the screw terminals of the IGW/936-L.

Terminal	Signal	А	В
A1	COM2 Serial Port: RS485 RX/TX+	1234	1234
A2	COM2 Serial Port: RS485 RX/TX-	eque	0000
A3	Vin + (12 24 VDC)		IGW/936
A4	Vin -		
B1			
B2	COM3 Serial Port: TXD (RS232), RX/TX- (RS485)		
B3	COM3 Serial Port: RXD (RS232), RX/TX+ (RS485)		
B4	Signal Ground		

Table 6: Pinout of the screw terminals



Please note:

The RS485 (officially called TIA/EIA-485-A) connection between your IGW/936-L and the field devices needs termination resistors on both ends for proper operation. The IGW/936-L **does not offer internal termination resistors**. Please make sure, that the RS485 cable connection is equipped with external termination resistors.



9 LED FUNCTIONS

LED	Description	Off	Flash	On
	Power	No Power		Power On
2	Wireless	Always Off		
S1	System	Not ready	Booting	Ready
S2	Modem/VPN	Off	Connecting	Ready

Table 1: LED functions

The LED S2 shows the modem state by different flashing provided the modem is used.

After the modem connection is established and VPN is enabled, the **LED S2** shows the state of the VPN connection.

The following table describes the functions of the particular LED signals.

On Time	Off Time	Description
Permanent		Modem connected or/and VPN connected
0.9 s	0.1 s	Good mobile signal (20 ASU - 31 ASU)
0.3 s	0.3 s	Normal mobile signal quality (13 ASU - 19 ASU)
0.1 s	0.9 s	Bad mobile signal quality (0 ASU - 12 ASU)
1 s	1 s	VPN-client tries connecting the VPN-server
2 s	2 s	Modem in init sequence, missing antena, unknown sig- nal
	Permanent	Unknown state, modem disabled, wrong PIN, VPN disconnected

Table 1: LED S2 functions



10 TROUBLE SHOOTING IP ADDRESS PROBLEMS

If the IP addresses of LAN1 and LAN2 are not configured properly it is possible, that the SSV/WebUI (the configuration user interface) of the IGW/936-L cannot be accessed anymore.

In that case it is necessary to restore the factory settings of the IGW/936-L. To do so please follow these steps:

- Connect the LAN1 interface of the IGW/936-L via a cross-over-cable with the LAN interface of a Windows PC. Disconnect (if present) the cable from the LAN2 interface of the IGW/936-L. If not already running turn on the IGW/936-L.
- **2.** Make sure that DHCP (IP address is obtained automatically) is enabled within the network settings of the Windows PC for the LAN interface.
- 3. Take a USB memory stick and format it under Windows with FAT16 or FAT32.
- **4.** Create a new simple text file on the memory stick, name it **factoryreset** and remove the file extension.



Please note:

Keep in mind that Windows hides file extensions by default!

- **5.** At first unmount the memory stick over the USB symbol in the Windows system tray before removing it from the PC.
- 6. Now plug the memory stick into the USB port of the (running) IGW/936-L.
- 7. The IGW/936-L makes a reboot and the LED S1 turns off after 15 to 30 seconds.
- 8. Remove the memory stick (at the latest when the LED S1 begins to blink).
- 9. The Windows PC shows the message Network restricted after 30 to 60 seconds.
- 10. The IGW/936-L answers via UPnP with its new IP address within the AutoIP range of 169.254.x.x. It can now be found as an icon within the Windows network environment. A double click on this icon opens the IGW/936-L's login page in a browser. The URL of the login page looks like this: http://169.256.x.x:7777.



11 HELPFUL LITERATURE

- IGW/936 hardware reference manual
- eSOM/3517 hardware reference manual

CONTACT

SSV SOFTWARE SYSTEMS GmbH

Dünenweg 5 30419 Hannover

Phone: +49(0)511 • 40 000-0 Fax: +49(0)511 • 40 000-40 Email: info@ssv-embedded.de

Internet:www.ssv-embedded.de
Forum: www.ssv-comm.de/forum
Social: www.linkedin.com/company/ssv-software-systems

DOCUMENT HISTORY

Revision	Date	Remarks	Name	Review
1.0	2014-05-07	First version	WBU	ENE
1.1	2015-08-26	Edited chapter 1.1	WBU	ENE
1.2	2016-02-03	Edited chapter 6.1 and 6.2, added chapter 6.3 and 6.7	WBU	KDW
1.3	2016-06-15	Edited chapter 5.3, added chapter 9	WBU	HNE
1.4	2018-08-29	Added chapter 10	WBU	HNE
1.5	2020-09-15	Added power consumption in chapter 7	WBU	HNE
1.6	2023-07-07	Removed information about DVI interface	WBU	ENE

The contents of this document are subject to change without prior notice. SSV does not assume any liability and does not guarantee that the presented information is accurate or complete. The information in this document is provided 'as is' without warranty of any kind. Some names within this document may be trademarks of their respective holders.

© 2023 SSV SOFTWARE SYSTEMS GmbH. All rights reserved.