

# IGW/925 How to Change the SIM Card

## microHowTo



#### **SSV Embedded Systems**

Dünenweg 5 D-30419 Hannover

Phone: +49 (0)511/40 000-0 Fax: +49 (0)511/40 000-40 E-mail: sales@ssv-embedded.de

Manual Revision: 1.0 Date: 2013-05-03



## **CONTENT**

1 INTRODUCTION	3
1.1 Safety Guidelines	3
1.2 Conventions	3
2 CHANGING THE SIM CARD	4
Step 1	4
Step 2	5
Step 3	6
Step 4	
Step 5	8
Step 6	9
Step 7	10
. 3 HELPFUL LITERATURE	
CONTACT	12
DOCUMENT HISTORY	12



#### 1 INTRODUCTION

This document describes how to change the SIM card of the socket modem inside the IGW/925.

#### 1.1 Safety Guidelines

Please read the following safety guidelines carefully! In case of property or personal damage by not paying attention to this document and/or by incorrect handling, we do not assume liability. In such cases any warranty claim expires.



**ATTENTION**: Observe precautions for handling – electrostatic sensitive device!

- Discharge yourself before you work with the device to avoid damages, e.g. by touching a heater of metal.
- Stay grounded while working with the device to avoid damage through electrostatic discharge.
- Remove **ALL** cables from the device before you open it, especially the power cable.

#### 1.2 Conventions

Convention	Usage
bold	Important terms
italic	Filenames, user inputs
monospace	Pathnames, program code, command lines

**Table 1: Conventions used in this Document** 



## 2 CHANGING THE SIM CARD



**ATTENTION**: Please follow the safety guidelines in **chapter 1.1** before you start!

#### Step 1

Use a screwdriver to push open the two lockings on top of the case like shown in figure 1.

Please be careful and do not push too strong!

Pay attention with the screw terminals (red indication) and do not remove them!




Figure 1: Pushing open the top lockings of the case



Now use the screwdriver to push open the two lockings at the bottom of the case like shown in figure 2.

Please be careful and do not push too strong!




Figure 2: Pushing open the bottom lockings of the case



Now pull the two parts of the case apart like shown in figure 3.




Figure 3: Pulling the case open



You now can see the SIM card holder. Unlock the holder by gently pushing its top part like shown in figure 4.




Figure 4: Unlocking the SIM card holder



Now flip open the holder and insert the new SIM card into the holder in the same orientation like shown in figure 5.




Figure 5: Inserting a new SIM card



Close the SIM card holder and gently push the top part like shown in figure 6 to lock the holder again.




Figure 6: Locking the SIM card holder



To close the case it is **very important** to carefully slide the boards into the bearings of the case and push the two parts gently together.

Figure 7 shows the top bearings.




Figure 7: Sliding the boards into the top bearings








Figure 8: Sliding the boards into the bottom bearings

Just push the case together until the four lockings snap in.

That's all!



#### 3 HELPFUL LITERATURE

• IGW/925 hardware reference manual

#### CONTACT

#### **SSV Embedded Systems**

Dünenweg 5

D-30419 Hannover / Germany

Phone: +49 (0)511/40 000-0 Fax: +49 (0)511/40 000-40

E-mail: sales@ssv-embedded.de

Internet: www.ssv-comm.de

Support: www.ssv-comm.de/forum

#### **DOCUMENT HISTORY**

Revision	Date	Remarks	Name
1.0	2013-05-03	first version	WBU

The content of this document can change any time without announcement. There is taken over no guarantee for the accuracy of the statements. The user assumes the entire risk as to the accuracy and the use of this document. Information in this document is provided 'as is' without warranty of any kind. Some names within this document can be trademarks of their respective holders.

 $\ensuremath{\mathbb{O}}$  2013 SSV EMBEDDED SYSTEMS. All rights reserved.